



**Accurate adjustment of the drive belts** is critical for a smooth running compressor and extended belt life. Slotted holes are provided on the smaller units that have one belt to aid in sliding the motor to tighten and align the belt. On the larger units, 15 and 20 hp, the compressor modules consist of two pumps and one motor. Aligning two belts accurately at the same time can be tricky, our newest design incorporates an idler pulley allowing motor and pumps to remain stationary while tension is made by the an idler pulley adjustment.

Innovation our competitors can only copy!



Creating Medical Gas Solutions...for Life